

## PANEL SYSTEM (BATON DRAW) INSTALL INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE.

### Baton Draw

#### Getting Started:

Please read through all instructions carefully before you begin installation.

Unpack all materials making sure all components are included:

- Assembled Panel System track
- Brackets
- Baton
- Counterweight, optional

Please note that your brackets must be securely attached to the mounting surface. If your screws do not hit wood studs you'll have to use a different fastener, which can be found at any local hardware store.

#### Tools You Will Need:

- Drill with a 1/8" bit and a Phillips bit
- Phillips screwdriver
- Metal tape measure

### Installing Your Panel System (Baton Draw):

You are now ready to install your panel system hardware.

#### Wall Mount:

- 1. Measure**  
Rails are pre-cut to your specified size.
- 2. Mark**  
Mark the height you would like the top of the panel rail to be installed. Note: The top of the panel will hang down approx. 1 1/8" from top of rail to top of the panel.
- 3. Attach Bracket**  
Attach your brackets to your desired area. Drill screws through holes for a secure mount. Repeat this process for all other brackets.
- 4. Attach Track**  
Insert track onto bracket and turn swivel to lock in place.
- 5. Attach Baton**  
Attach baton to the baton adaptor.
- 6. Optional Counterweight**  
Slide counterweight into bottom hem pocket.

#### Ceiling Mount:

- 1. Measure**  
Rails are pre-cut to your specified size.
- 2. Attach Bracket**  
Attach bracket to ceiling by first pre-drilling holes for screw diameter when mounting into a ceiling stud. Otherwise, pre-drill and install anchors first before fastening with screws. Tracks hold 6 lbs/ft. Support brackets occur every 4 feet.
- 3. Attach Track**  
Insert track into bracket applying pressure until it "clicks" into place.
- 5. Attach Baton**  
Attach baton to the baton adaptor.
- 6. Optional Counterweight**  
Slide counterweight into bottom hem pocket.